

A/C Installation Instructions

Parts List

- 1 – Window Template 11 1/8” x 17”
- 2 – 2” Street Elbows, 90 degrees
- 2 – 2” Hub/ Hub Elbows, 90 degrees
- 2 – 2” x 12” Straight Pipe
- 8 – 1/4” x 3/4” Bolts
- 8 – 1/4” x 3/4” Hex Nuts

STEP 1:

- Remove 2 Bolt on fittings from A/C Box
- Remove Window template, nuts and bolts from kit



STEP 2: Install bolt on fittings to window template with the 8 nuts and bolts



STEP 3: Using the hub/ hub elbows, connect to window template by gluing, or taping 2 wraps of electrical tape, to make firm fit.



STEP 4: Press straight pipe into hub elbow and street elbow at the other end.



STEP 5: Using rubber hose form A/C unit, connect to window template by placing rubber hose over street elbow and clamping in position with steel squeeze clamps provided in A/C.



STEP 6: Install window template in window of the trailer.



OUTSIDE



INSIDE

Finishing Up: Make a connection to the template once it is installed in the trailer window frame. Repeat for the second pipe connection.



Set it on the ground with a Retro Model



Set it up front with a Platform Model

If you have any questions, feel free to give us a call at 1-877-545-4897.
For technical support call Donnie at (330) 327-4659.

Stay Cool,

